meusburger

MATERIAL NO.:	1.3343 (HSS)						
DESIGNATION: DIN:	HS 6-5-2 C	TEC	TECHNICAL TIP:				
AFNOR:	Z 85 WDCV 6 X 82 WMoV 6 5			Due to the high tempering resistance, excellent for PVD and PACVD coating.			
UNI:							
AISI:	M 2 reg. C				D coating.		
INDICATORY ANALYSIS:	C 0.9						
	Si 0.3						
	Mn 0.3						
	Cr 4.0						
	Mo 5.0						
	V 1.9						
CTDENICTU	W 6.2						
STRENGTH:	max. 269 HB						
	(≈ max. 915 N/mm²)						
THERMAL CONDUCTIVITY AT 100 °C:	27.4 <u>W</u> m K						
COEFFICIENT OF THERMAL EXPANSION	100° C	200 °C	300 °C	400 °C	500 °C	600 °C	700 °C
[10 ⁻⁶ /K]	10.8	11.8	12.0	12.5			
CHARACTER:	» High-speed steel featuring high resistance to adhesive and abrasive wear in						
	combination with high toughness and compressive strength						
APPLICATION:	>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>						
	extrusion punches and dies, inserts with a very high wear resistance						
TREATMENT BY:	» Polishing:						
	suitable						
	» Nitriding:						
	highly suitable						
	» EDM:						
	highly suitable						
	» Coating:						
	highly suitable						
HEAT TREATMENT:	» Soft annealing:						
	820 to 850 °C, about 2 to 5 hours						
	slow controlled cooling inside the furnace of 10 to 20 °C per hour to about 550 °C;						
	then further cooling in air, max. 270 HB						
	>> Hardening:						
	1190- 1230 °C quenching in oil/compressed gas/air/hot bath						
	quenching in oil/compressed gas/air/not bath obtainable hardness: 66 HRC						
	» Tempering	1:	6 HRC		forming of a	cracks) imme	diately afte
	✗ Tempering slow heating	1: ng to temper	6 HRC	ture (to avoid	forming of a	cracks) imme	diately afte
	Tempering slow heating hardening	1: ng to temper ;	6 HRC ing tempera		forming of a	cracks) imme	diately afte
TEMPERING CHART:	Tempering slow heating hardening	1: ng to temper	6 HRC ing tempera		forming of c	cracks) imme	diately afte
TEMPERING CHART:	Tempering slow heating hardening triple temp	1: ng to temper ;	6 HRC ing tempera		forming of c	cracks) imme	diately afte
TEMPERING CHART:	Tempering slow heating hardening triple temp	1: ng to temper ;	6 HRC ing tempera		forming of c	cracks) imme	diately afte
TEMPERING CHART:	>> Tempering slow heatin hardening triple temp HRC 70	1: ng to temper ;	6 HRC ing tempera		forming of a	cracks) imme	diately afte
TEMPERING CHART:	Tempering slow heatin hardening triple temp HRC	1: ng to temper ;	6 HRC ing tempera		forming of c	cracks) imme	diately afte
TEMPERING CHART:	 Tempering slow heatin hardening triple temp HRC 70 65 	1: ng to temper ;	6 HRC ing tempera		forming of c	cracks) imme	diately afte
TEMPERING CHART:	>> Tempering slow heatin hardening triple temp HRC 70	1: ng to temper ;	6 HRC ing tempera		forming of c	cracks) imme	diately afte
TEMPERING CHART:	» Tempering slow heatin hardening triple temp HRC 70 65 60 60	1: ng to temper ;	6 HRC ing tempera		forming of a	cracks) imme	diately afte
TEMPERING CHART:	» Tempering slow heatin hardening triple temp HRC 70 65 60 55	1: ng to temper ;	6 HRC ing tempera		forming of c	cracks) imme	diately aft